

## Loading Amadas-Specific Payload for CDU

All of the controller payloads for the 9970 SP Combine are the same as the John Deere 9570 Combine payloads except for the CDU controller. This controller requires an Amadas-specific payload.

The **AH231068A\_9101** payload file is used to configure the CDU controller. Refer to “How to Install the CDU Payload into Service Advisor” document in the Technical Bulletins section to obtain this payload.

Once you have the payload in the Service Advisor, it can be downloaded to the CDU following the same routine for all other payloads. Once the payload is loaded, however, certain addresses must be checked or changed for the combine to function properly. A listing of these addresses can be found in “Machine Setting Addresses to be Set/Checked” in the A9907 SP Peanut Combine Electrical Information manual supplied with the combine. A copy of this manual can also be found in the Parts Catalog and Manual Section of this website under A9970 SP Combines.