


Form 0358 - Programming Instructions for 16395 for Different Machine Applications - (16395 replaces 16942 and 15515) - 10/18/10

IMPORTANT!

If your tachometer comes with this notice in the box [orange], use tach settings from Form 0359!



In order for the display to show the correct values, the DT8 Red Lion Rate Meter (Amadas part number: 16395) must be programmed before installation. Below are the DIP Switch settings for your application.

SWITCH SETTINGS

	SWA								SWB					
	1	2	3	4	5	6	7	8	1	2	3	4	5	6
ON														
OFF														

Machine	"ON" DIP Switches	
	SWA	SWB
8557 2-Row Peanut Combines; <1990 (up to Serial #280000)	1,2,3,4,5,6	1,2,3,6
4&6 Row Pull-Type Peanut Combines; 1990&1993 machines (Serial #280000-310000) [S16942]	1,2,3,4,5,6	1,2,3,6
4&6 Row Pull-Type Peanut Combines; 1994 to 2004 machines (Serial #320000-429999) [S16942-1]	4,5,7,8	2,3,4,6
4&6 Row Pull-Type Peanut Combines; (Serial #430000-Present)	3,5,6,7	1,2,3
2002 Model ADI-2 Digger/Inverters (Serial #400000) [70640]	2,5,7,8	6
ADI-4&6 Digger/Inverters; 2002 to 2003; (Serial #400000 - with pick-up on conveyor shaft) [70600 - 4-ROW; 70631 - 6-ROW]	2,3,5,7,8	1,6
ADI-430,-436,-438,-630,-636,-638,-640 Digger/Inverters; (Serial #400000 - Present with pick-up at motor) (displayed as MPH) [S15465-1]		1,6
ADI-430,-436,-438,-630,-636,-638,-640 Digger/Inverters; (Serial #400000 - Present with pick-up at motor) (displayed as KM/H) [S15465-1M]	2,4,5,8	1,6
1400,2000&3000 Irrigators w/Turbine Drive;1993-1999 (Serial #310000-370000)	1,2,3,5	6
1400,2000&3000 Irrigators w/Hydrostatic Drive; 1993-1999 (Serial #310000-370000)	2,3,7	6
1030 Irrigators; 1998-Present (Serial #360000-Present)	8	6
1400,2000&3000 Irrigators; All Drives (Serial #380000-Present)	4,7	6
C1325/1375 Irrigators; (Serial #430000-Present)	7	6